

# QUICK START GUIDE

Please read instruction manual thoroughly before using this product, and watch our instructional video at [www.perlagesystems.com/support](http://www.perlagesystems.com/support)



## 1. PLACE BOTTLE IN ENCLOSURE

The enclosure consists the shell (1), the cap assembly (2), the base (3), and a removable cup-shaped booster (4) that sits in the base.

Always remove base and cap completely from clear shell before inserting bottle. Set bottle in base with removable booster concave side *up*, then place clear shell over bottle and screw it *lightly* into base.



**!** *Lip of bottle should protrude **NO FURTHER THAN 3/8"** from shell, as in Figure 2. If bottle protrudes further, do not use.*

## 2. CHECK BOOSTER ORIENTATION

If the shell “bottoms out” before engaging the flange of the bottle, the bottle will not be held securely in the enclosure. Flip the removable booster in the base so it is concave side down, as shown in (b) in Figure 3, and replace the shell.



## 3. PURGE OXYGEN

Place the tip of the pressurizer just inside the lip of the bottle, then press the trigger on the pressurizer for 3-5 seconds (Figure 4).



## 4. SCREW CAP ONTO SHELL

Screw cap down until valve just makes contact with top of bottle. Twist lightly no more than another **half turn**. Finger tighten only.

**!** ***DO NOT OVERTIGHTEN CAP. Repeated overtightening can damage both cap and valve, and make cap difficult to remove.***



## 4. REPRESSURIZE BOTTLE

Press tip of filler securely into conical depression in cap. Press trigger and hold until gas stops flowing. This will take about 3-5 seconds, depending on how full the bottle is.

**!** ***DO NOT POINT CAP AT SELF OR ANYONE DURING PRESSURIZATION OR AFTER BOTTLE IS PRESSURIZED.***



## 5. REMOVE CAP SLOWLY AND SERVE

Remove cap *slowly* to let gas escape. You may pour directly from enclosure, or remove the bottle from the enclosure to serve.

Questions? Call us at (866) PERLAGE, or email us at [support@perlagesystems.com](mailto:support@perlagesystems.com), or visit [www.perlagesystems.com/support](http://www.perlagesystems.com/support)

# PRODUCT SAFETY

*Compressed gases must be handled with care. Failure to do so may result in injury. Please read and follow instruction manual carefully before using this product, and watch our instructional video at [www.perlagesystems.com/support](http://www.perlagesystems.com/support).*



## DO NOT OVERTIGHTEN CAP

Repeated over tightening of cap can damage both cap and valve, and make cap difficult to remove. Tighten cap no more than one-half turn after valve makes first contact with lip of bottle. Finger tighten only.



## DO NOT POINT PRESSURIZED UNIT AT OTHERS

Do not point cap at yourself or anyone else while pressurizing, or after bottle is fully pressurized. Keep cap pointed away from face while pressurizing.



## DO NOT LET UNAUTHORIZED PERSONS HANDLE

The Perlage System should only be used and handled by trained personnel who have been instructed in its use. In particular, pressurized unit should not be handled by customers or bystanders.



## USE ONLY WITH HIGHLY SPARKLING WINES

Do not use the Perlage System for uncarbonated or slightly carbonated wines or other beverages. If the bottle does not have a collar near the lip, and a cork with a wire cage, it should **NOT** be used in this product. The glass may not be strong enough to contain the pressure of the Perlage System, and without a proper flange, the bottle may protrude too far from the shell, resulting in the cap not properly engaging the threads of the shell.



## DO NOT USE DISHWASHER ON THIS PRODUCT

Do not use dishwasher to clean the Perlage System. Hot water can weaken the components and degrade the valve. Hand wash periodically in hot, soapy water. Regular cleaning will keep the valve clean, and prevent the base and cap from sticking.



## DO NOT USE THIS PRODUCT IF DAMAGED

Inspect the Perlage System regularly. Do not use if there is any visible damage to the enclosure.

# REORDERING

To order more enclosures or pressurizers for the Perlage Commercial System, or for any product assistance or questions, please email us at [info@perlagesystems.com](mailto:info@perlagesystems.com), call us at **(866) PERLAGE**, or visit our Web site at [www.perlagesystems.com](http://www.perlagesystems.com). We will direct you to a Perlage Systems distributor in your area who will be able to assist with product installation and service.

*Questions? Call us at **(866) PERLAGE**, or email us at [support@perlagesystems.com](mailto:support@perlagesystems.com), or visit [www.perlagesystems.com/support](http://www.perlagesystems.com/support)*